



Printing and Transfer Instructions

Recommended for White and Light colored Fabrics only

WHY IS THIS PRODUCT UNIQUE?

- Soft hand
- Transferred images appear “natural”
- Transferred images with no cracking
- Iron directly on transferred images without the coatings “sticking” to the iron
- Hot or cold Peel has similar Image characteristics
- Iron or heat press gives similar image appearance
- Can be used on different Fabrics
- No special laundry instructions are necessary

IMAGE PRINTING

DO NOT OVERSATURATE COLORS. IT WILL NOT ENHANCE TRANSFER QUALITY. A LITTLE COLOR GOES A LONG WAY.

- Design or select image on the computer.
- Mirror image before printing
- Print image on the coated side of transfer paper
- Allow the printed image to dry before transferring

HEAT TRANSFER APPLICATION

Commercial Heat Press

- Set heat press at 375- 400 degrees Fahrenheit and allow coming to set point
- Set press for medium pressure.
- Pre-heat garment for a few seconds to remove moisture or wrinkles.
- Place transfer paper face down and press for 25- 30 seconds
- Remove paper hot or cold.

Home Hand Iron

- It is best to use a smooth, hard, non-porous surface.
- Preheat the iron on the highest setting (**Cotton/Linen**). Do not add water to the iron
- Allow the iron to pre-heat for 5mins.
- Place a pillowcase on the ironing surface. Iron to remove wrinkles.
- Pre- iron the fabric to remove any moisture and wrinkles
- Place transfer paper face down onto your garment.